

Tips for using your ABS s nap onto tubing clamps



OPTIONAL

Use fiberglass reinforced tape with one full wrap around the clamp. Start on the outside and fold tape around to the inside cut tape off leaving about 8" hanging out. fold that over onto itself making a pull tab

To install clamp onto tubing, start pushing the clamp at the corner then rotate snapping the clamp in place

Pull the tape tab to quickly remove the clamp